

Forced Air Central Heating Systems Plucking Brands from the Flames

Whose woods these are I think I know, his house is in the village though. He will not see me stopping here, to watch his woods fill up with snow. – Robert Frost

Winter is drawing near. It's whispered about amongst the trees. It's carried on the thin shoulders of the blustery wind. It's scrabbling up from the earth upon which you tread. Very soon, it will be the quiet white of morning cold.

With cold comes our animal need for heat. When Prometheus thieved a spark from Zeus' lightning bolt, Prometheus protected the flame in a fennel stalk and delivered the smoldering bundle to mankind, which discovered fire. Zeus punished Prometheus by chaining him to the side of a mountain to suffer eternal punishment, where his liver was pecked incessantly by an eagle (no need to get all squeamish, it was actually one of the relatively painless punishments in the annals of Greek mythology).

And never fear, the story ended well. Prometheus (sans liver) was saved by Heracles and, *almost* as importantly, mankind retained our ability to harness the power of fire for heating. Ever since, fire has been used for heating, whether for camp, cave, castle, hut or home.

Thankfully, "fire" has come a long way, baby. No more days of huddling by the hearth or bubbling brew over open flames. When we use the word "fire" nowadays, particularly in the context of home heating, we're referring to the various methods used to heat the *modern* home.

In this edition, we discuss the most popular home heating system – forced air central heating, which generates heat and "forces" warm air via ductwork to various points in a house.

Maybe Not Medieval But Definitely Not Modern

Forced air heating may be the most popular central heating system in North America, but to refer to the system as "modern" is a significant truth stretch because forced air central heating systems are decidedly *unmodern* – although certain parts of the system have evolved, using air to heat a home has been around since the 1930s, and, some would argue, all the way back to the Roman Empire. What does that say about mankind?

So although there have been innovations over the last 80 years, the basic concept remains – air is heated and "forced" through a system of ducts and vents into different rooms of a home. What *that* says about mankind is a preference for simplicity because despite being inefficient to operate, forced air central heating systems generally are simple, and inexpensive, to install.



Toasty Trifecta: Heating Source, Forced Air, and Ductwork

A forced air central heating systems is comprised of three components:

- Heating source the method for generating fire and heat, e.g., furnace
- Distribution method the method for "forcing" the heat throughout the house, e.g., blower
- Distribution network the structure which carries the forced hot air, e.g., ductwork

The heating source is the variable part of the system, i.e., even though there are lots and lots of different ways to generate heat, the distribution method and the distribution network generally are similar. Theoretically, you could build a bonfire in your basement to generate and push heat to the rest of your house using forced air, but thankfully, furnaces generate heat in a controlled manner so you don't need to risk building a biomass hot mess.

Come On Baby, Light My Fire: Heating Sources

Step one in a forced air central heating system is to harness a heating source. Popular systems include gas furnace, oil furnace, hydro-air, heat pump and electric furnace.

Gas Furnace

The most common heating system is the gas furnace, which has pipes that deliver gas to an air handler; gas is attached to a regulator that turns gas flow on when your thermostat says "Give me more of that unforgettable fire."

Furnaces that burn natural or propane gas have tubes with small holes which are ignited when heat is required; these tubes are similar to tubes in a gas grill. Burner flames are surrounded by metal which is heated and the heat exchanger transfers heat from the flames to the air. In high efficiency units, there is a secondary heat exchanger which captures heat from the primary heat exchanger and circulates warmer air.

There are three common types of gas piping: black iron, corrugated stainless steel tubing (CSST) and copper. Because most states no longer permit copper piping, our professional inspectors generally recommend replacing copper with CSST or black iron.

Regardless of piping type, our inspectors also recommend periodically checking your gas lines for leaks from the gas meter to the gas regulator at the air handler The easiest method to test for leaks is good ol' fashioned soap n' water. Pour or spray soapy water on connections. If there are bubbles, be afraid, be very afraid – there's a leak. Gas leaks are deadly serious – call the gas company or a plumber immediately.

Oil Furnace

Oil burning furnaces work slightly differently than gas furnaces because the fuel is liquid instead of gas. Oil furnaces utilize storage tanks from which oil is pumped to the furnace, run through a filter, sprayed



through a nozzle, and ignited into a combustion chamber. The combustion chamber serves a similar function as heat exchangers for gas furnaces.

Regardless of gas or oil, byproducts of burning fuels need to be expelled outside the home; one byproduct is carbon monoxide (CO), which can be dangerous and deadly if not properly expelled from the home.

When exhausts cool, they produce water that contains corrosive acids; therefore, a CO exhaust system must be sloped upward and properly sized to ensure that exhaust doesn't condense. Normally, small drops of water and acids are diluted above where exhaust exits the flue but if the exhaust is allowed to condense in the flue, it can chomp on the metal and allow exhaust to enter the home. Therefore, if there is rust, especially at the joints or elbows of the furnace exhaust, our inspectors recommend that you retain a contactor to make repairs and determine if the flue is properly sized for the furnace. An exhaust system also needs to be sized properly to allow draft to penetrate exterior air pressure, especially in colder climates.

Our inspectors also generally recommend installing CO detectors in high traffic areas near bedrooms, garages and on each floor of your home. Test the CO detectors every quarter. Our inspectors also recommend checking oil tanks and lines for leaks, changing the oil filter, and cleaning nozzles on a regular basis.

Hydro Air Furnace

A hydro air system is a combo hot air *and* hot water system. A central hot water boiler (gas or oil) generates heat and pumps water through small diameter tubing to an air handler unit which contains a hot water coil, an air conditioning coil, and a blower. As hot water heats the coils, a blower passes air over the coils and distributes the air via the ductwork.

Hydro air systems generally are smaller and more efficient and because there can be multiple air handlers which can be placed practically anywhere, installation and zoning can be very specific and customized to each house. However, the air isn't as warm and there is heat loss as water runs from the water heating source to the air handler.

Heat Pump

Heat pumps are common in moderately warm areas. Heat pumps capture heat from the exterior and transfer it to the interior; captured heat is distributed through copper coils in an air handler and air is blown over the coils to transfer the heat to the rest of the home.

When it is too cold outside to capture enough heat to keep the house warm, heat pumps sputter, raise the white flag, and ask the electric grid for help. For those of us with heat pumps and electric backup, we cringe on cold, blustery days when the thermostat LCD kindly notes that the heat pump is on "emergency heat" i.e., we're paying out the wazoo!



Electric Furnace

Electric furnaces are common in warmer climates (e.g., southern FL) where heat is required infrequently (because operating electric furnaces is so darned expensive). However, they're low maintenance and because they are not used on a long-term regular basis, the systems generally last longer than other heating systems.

The Forcing of "Forced Air:" Distribution Method

Creating fire is a very good place to begin if you're planning a central heating system. However, the magic of "forced air" systems is in the actual *forcing*, which is somewhat of a misnomer because "forced" is such a violent term; the actual operation is more gentle because, after all, we're referring to gentle puffs of warm air. (Historical note: Older central heating systems used gravity, like fireplaces, so it was warm near the source and cold further away; "forced" was used as a selling point to indicate even distribution.)

Regardless of heat source, distribution for all air furnaces is similar. For purposes of this brief overview, we'll review the *heart* of the distribution network – the air handler. There certainly are other parts but the air handler is what forces the forced air.

The air handler is a metal box which connects the supply and return air ductwork; the air handler also where the burners are located. Like a heart, which ingests deoxygenated blood and pumps out rejuvenated oxygenated blood, an air handler ingests cooled air, reheats the air, and blows warmed air throughout the home. The air handler consists of several different sections: return air, blower fan, and a plenum, which connects the ductwork to the home.

The return air component is normally where the air filter is located; this contains the air filter that you always forget to remember. Just past the return air connection and the filter is the blower motor; the motor should be sized to deliver air with adequate velocity to the furthest point in the house. The blower motor determines not only the outgoing heat through the vents but also how much air gets sucked back into the return air vent on the other side of the room. The blower motor, along with the ductwork layout, is integral in circulating the air sufficiently to have even heating and not create hot and cold spots in the home.

The next section of the air handler is where the air blows over the heat exchanger or coils and the heat from the fuel source is transferred to the air, and last but not least, is the plenum, which is the connection point for the air handler and the ductwork and is the beginning of the supply side of system. The plenum often has a flexible connection which serves two purposes – to give some allowances for the ductwork to matchup to the air handler and secondly to act as a damper that reduces noise vibrations from being transmitted through out the ductwork.

I Can Feel It Coming In the Air Tonight: Distribution Network

So you've got a lot of hot air and a blower. (Sound like anyone you know?) Now you need a way to get the heat from Point A (the heater/blower) to Point B (that frigid room over your garage).



That's where ductwork comes in – you may have noticed shiny metal tubes which look like fragile aluminum foil. It's not really aluminum foil, it's very thin sheet metal wrapped around plastic ribs (*or* very thin plastic wrapped around metal ribs). There's lots of different types of ductwork, including asbestos panels, fiberboard and wall chases, wood and sheetrock. If air can pass through it, it can be used as ductwork.

The ductwork may appear to be a relatively unintelligent part of the entire system because the ducts just "sit there." Don't be fooled – the design and installation of ductwork are incredibly important to the efficient heating (and cooling) of a house.

The problem with ductwork is that it generally insulates as about as well as aluminum foil, i.e., not well. Warm air bleeds away from the ductwork as the warm air travels from Point A to Points B, C, X, Y and Z – unless ductwork is insulated properly, heat will dissipate into the cold night.

As a general rule, if you can insulate ductwork, it works much better. At the very least, for the spaces in which ductwork is visible – attics, crawlspaces, basement – make sure your insulation is appropriate because even if you're not (yet) green, why pay good money to let your heat disappear?

We've conducted millions of inspections (yes, millions!) and the most common issue we discover during our inspections is ductwork that is disconnected or damaged. Please, for the sake of Zeus, if ductwork is in the attic, do *not* store items on top of it and *never ever* step on the ductwork. You'll squash it like a stinkbug.

In crawlspaces and basements, check to make sure that ductwork is connected, especially where the duct meets the vent. Because the floor moves with varying humidity and climate conditions through the year, *and* because people step on floor vents, the duct-vent boot connection also a common inspection problem.

We don't want to make you physically sick, but over a couple of years, your ductwork collect the same types of dust, hair, pet fur and dead skin that fall on your carpet or floors. Although the air filter will capture some of this detritus, some will settle into the ductwork. Therefore, for the sake of Zeus, ask a professional to clean your ducts periodically and certainly after any big home improvement project.

* * * * *

About Us Inspect

www.usinspect.com

US Inspect is the nation's leading inspection services firm, delivering residential and corporate relocation inspections since 1987. Our reputation is built on decades of honesty, integrity and excellent service to our customers at one of the most important decisions in their lives – buying or selling a home. We are committed to ensuring that each of our customers enjoys an exceptional inspection experience.

Please contact <u>marketing@usinspect.com</u> if you have any questions or require assistance.